

Assembly instructions

- Please review the instructions carefully to ensure no steps or details have been missed.
- Please follow the safety precautions carefully during assembly.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

-
1. Misuse and abuse of this product can cause serious injury.
 2. Read the instructions before using the product.
 3. Inspect before use and replace worn, defective or missing parts.
 4. Only allowed for adults to install and be used by adults's supervision.
 5. Place it on a flat surface, check all the parts are well connected before use.
 6. Product for Age: 3-8 years old.
 7. Only for domestic use.
 8. Maximum total weight 110LBS

This equipment is to be used only by properly trained, qualified persons under supervised conditions. Use without proper supervision is dangerous and should never be undertaken nor permitted. Manufacturer shall not be liable or responsible for personal injury or property damages incurred through use of this equipment

from gymnastics to playtime trusted quality for over 27 years


WHERE THE wild kids PLAY is the sister company of **ZAthletic**, dedicated to delivering professional-quality products directly to your home. By designing and selling our products in-house, we ensure the highest quality at the best prices.

With over 27 years of experience in crafting bars and foam products, we design with both gymnasts and families in mind - whether you're practicing at a gym or playing at home with your toddler. We look forward to you enjoying your new product!




The Wild Kids Sky Bar comes with a 1 year manufacturer's warranty.
contact us: hello@wildkidsplay.com

• Parts List



Side Support: 2parts




Spin Lock Knob: 2pcs



Adjustment Pole: 2pcs




Adjustment disc: 2pcs




Bar Rail: 1pcs




Base Bar: 2pcs



Screw: 7pcs (includes spare)




• Assembly Overview




• Assembly Instructions (Step 1)

For safety, we recommend having 2 people for assembly.



Unfold the Side Supports and screw on the Adjustment Discs (as shown in the figure)
The Side Support is fully unfolded when the Safety Bar reaches the Safety Bar Stop


● Assembly Instructions (Step 2)



Align the Side Supports and the Base Bars (as shown in the figure)
Line up screw holes, then insert and hand tighten the screws



Important: Spin Lock Knobs need to face outward, otherwise the Bar Rail (Step 4) cannot be secured with screws.

• Assembly Instructions (Step 3)



● Assembly Instructions (Step 4)


Adjustment guidelines




Align the Bar Rail with the Adjustment Poles (as shown in the figure)
Line up screw holes, then insert and hand tighten the screws

Note: If screw holes are not aligning correctly, please make sure Spin Locks are facing outward on the bar. Refer back to Step 2 if needed.


- **Height adjustment**



Loosen the Spin Locks by turning the knob counter clockwise.
Raise or lower the bar to the height you need.




Use the visual tick marks on the Adjustment Poles to align holes properly.
Before fully tightening the Spin Locks, ensure both sides are the same height level.
Tighten the Spin Locks into the new height hole by turning the knob clockwise.



If bar seems woobly or ground is uneven, rotate and adjust the base Adjustment Discs
to compensate for uneven flooring.

- **Folding for Storage**



Hold the Safety Bars on each side and pull upwards.
The Side Supports can be folded and closed as seen in the figure below.

